


# EASY INSTALLATION

Handle — 


Flange — 

Bonnet — 

Spindle — 

O-Ring — 

Washer — 

Tap valve — 

1. Turn off water at mains.
2. Remove tap handle; unscrew & remove spindle assembly.
3. Replace tap valve, fibre body washer & o-ring.
4. Apply FIX-A-TAP® waterproof lubricant to o-ring & spindle.
5. Reassemble spindle & handle.
6. Turn on water supply & inspect for leaks.

**FIX-A-TAP®**

**AUSTRALIA PTY LTD**

*The Ultimate Plumbing Solution*

PO Box 200 Wahroonga

NSW 2076 Australia

Made in Australia ©2025

[www.fixatap.com.au](http://www.fixatap.com.au)

#261120