

ALL DIRECTIONAL SHOWER - 15SH422CL

Caution:

When cleaning, use soap, water and a clean damp cloth only. Use of abrasive cleaners or harsh chemicals may void warranty.

Installation Instructions:

- Not suitable for gravity feed systems
- Pipework must be thoroughly flushed before installation as dirt and foreign materials may affect functionality of the product

Installation:

- Ensure nipple is correct length, cut if necessary
- Cover plate must be placed over male nipple before shower is attached
- Apply thread tape to male thread and ensure inlet is not blocked
- By hand (at the base of the shower arm) gently screw the female inlet onto the male thread, then using a spanner and cloth (to not damage the finish), tighten the shower to the desired position. Do not over tighten.
- **Warning** - Do not use arm as leverage when tightening shower on to male thread as this may result in damage to the shower

Pressure and Temperature requirements:

- Maximum inlet pressure: 1000kPa
- Regulation: 500kPa is the maximum operating pressure at any outlet within a building (AS/NZS 3500.1-2003, Clause 3.3.4)
- Inlet pressure should be equal for both hot & cold water
- Maximum operating temperature: 80°C

