




Basic Setting of Programs for the Flex Water Computer 1890-20















Flex Art. 1890



After inserting the battery, you will need to set the time as it will be flashing in the top left corner 00:00

Turn the dial  to the appropriate hour then press the tick button , do the same for the minutes.

To set the program follow steps below.





1. The clock  appears and the hours 00: will be flashing, turn the dial  to the desired hours then press the tick button 
2. The minutes :00 will now be flashing, turn the dial  to the desired minutes and press the tick 
3. The Hour Glass  appears with 00min flashing turn the dial  to the desired minutes and press the tick 
4. The 00sec will now be flashing turn the dial  to the desired seconds and press the tick 
5. The Calendar will appear  turn the dial  to choose your watering sequence, (from every 4 hours up to 72 hours) then press the tick 
6. Program ON will display **ON** press the tick 








Your program is now set.

To water manually

NOTE: For manual watering you must have the face of the controller fixed onto the body and connected to the tap.

1. Press the manual water button on bottom left hand side 
2. Turn the dial  to the desired duration and press the tick  watering will automatically start.
3. A symbol will appear next to the battery showing watering is now in operation  and will stop watering when it reaches the end of the set duration.

To adjust the time for daylight savings, etc

1. Slowly turn the dial  till the time in the top left corner of the screen begins flashing
2. Press the tick  button
3. Turn the dial  to adjust the hours and press the tick 
4. Turn the dial  to adjust the minutes and press the tick 