


EASY INSTALLATION



1. Turn off water at mains.
2. Remove tap handle; unscrew & remove spindle assembly.
3. Replace tap valve, fibre body washer & o-ring.
4. Apply FIX-A-TAP® waterproof lubricant to o-ring & spindle.
5. Reassemble spindle & handle.
6. Turn on water supply & inspect for leaks.

FIX-A-TAP®
AUSTRALIA PTY LTD

The Ultimate Plumbing Solution

PO Box 200 Wahroonga
NSW 2076 Australia
Made in Malaysia ©2025

www.fixatap.com.au

*Visit our website for
socials, plumbers,
product info & more*

#245182