




ADAPTOR REFERENCE LIST		
Type	Thread size	Compatible sprayers
D	18 mm male to 14 mm male	ABS1858B
G	14 mm female to 18 mm female	




NOTE: The boom sprayer accessory is used with adaptor D and adaptor G to be compatible with ABS1858B.





NOTE: The boom accessory can be attached as a nozzle to the nozzle wand.






Turn the nozzle on the nozzle wand counterclockwise, and remove it from the nozzle wand.



Attach the 14 mm female thread of adaptor G to the nozzle wand. Turn the adaptor clockwise to tighten.





NOTE: The boom accessory sprays 4 streams to maximise the area sprayed by the product.

NOTE: A small amount of liquid will drip from the nozzle after releasing the trigger.